

Accessories

Part Number	Description	Specifications	Used With:
SA-1050	Flydeck ¹	2 ft (0.6 m) Rated working load: 250 lbs. (113.4 kg) each	ST-17, ST-180, 701086-1 Steel Work Cage
SA-1051	Flydeck ¹	3 ft (0.9 m) Rated working load: 250 lbs. (113.4 kg) each	ST-17, ST-180, 701086-1 Steel Work Cage
SA-1052	Demountable Flydeck ¹	2 ft (0.6 m) Rated working load: 250 lbs. (113.4 kg) each	ST-19
SA-1053	Demountable Flydeck ¹	3 ft (0.9 m) Rated working load: 250 lbs. (113.4 kg) each	ST-19
701114-1	Flydeck ¹	2 ft (0.6 m) Rated working load: 250 lbs. (113.4 kg) each	700903-1 Collapsible Aluminum Work Cage
700934-1	Flydeck ¹	3 ft (0.9 m) Rated working load: 250 lbs. (113.4 kg) each	700903-1 Collapsible Aluminum Work Cage
Various*	Ladder-Type Aluminum Plank	Designed for a plank 12-28 in. (305-711 mm) wide with a rail depth of 3 3/4 – 6 in. (95-152 mm)	All hoists
SA-1035	Philly Wall Roller	<ul style="list-style-type: none"> Attaches to any side of basket or work cage Polyurethane caster-style wheel Set includes two philly wall rollers with attachment hardware 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage
701036-1**	Adjustable Face Roller	<ul style="list-style-type: none"> Attaches to top rail, midrail or corner upright post Designed for use against relatively fragile structures, 11 in. (279 mm) wide, soft rubber rollers distribute weight evenly to prevent structural damage Set includes two roller brackets, four rail clamps and rollers 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage
SA-1036-3**	Face Roller	<ul style="list-style-type: none"> 3 Roller Assembly Attaches to top rail, midrail or corner upright post Designed for use against relatively fragile structures, 11 in. (279 mm) wide, soft rubber rollers distribute weight evenly to prevent structural damage Set includes two roller brackets, four rail clamps and rollers 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage
SA-1036-4**	Face Roller	<ul style="list-style-type: none"> 4 Roller Assembly Attaches to top rail, midrail or corner upright post Designed for use against relatively fragile structures, 11 in. (279 mm) wide, soft rubber rollers distribute weight evenly to prevent structural damage Set includes two roller brackets, four rail clamps and rollers 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage

For additional Flydeck information see page 73.

¹ Flydecks are sold as a set of 2

*Available in rental fleet only **See page 91.

Accessories

Part Number	Description	Specifications	Used With:
SA-1036-5**	Face Roller	<ul style="list-style-type: none"> 5 Roller Assembly Attaches to top rail, midrail or corner upright post Designed for use against relatively fragile structures, 11 in. (279 mm) wide, soft rubber rollers distribute weight evenly to prevent structural damage Set includes two roller brackets, four rail clamps and rollers 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage
SA-1037**	Adjustable Wall Bumper Roller	<ul style="list-style-type: none"> Allows operator to adjust the distance between the rollers and the stage, as well as the distance between the rollers Set includes: two roller brackets, four rail clamps and rollers 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage
SA-1090**	Adjustable Wall Roller	<ul style="list-style-type: none"> Allows operator to adjust the distance between the rollers and the stage, as well as the distance between the rollers Set includes: two rollers and four rail clamps 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage
701037-1**	Face Roller Assembly	<ul style="list-style-type: none"> Foam face roller assembly (11 in. [279 mm] length x 6 in. [152 mm] diameter) for aluminum work cage Extendable outreach from 11-18 in. (279-457 mm) from base of work cage Set includes one roller bracket, four rail clamps and roller 	700903-1 Collapsible Aluminum Work Cage
SA-1045	Rail Clamps	<ul style="list-style-type: none"> Clamps face roller assemblies to standard Spider baskets 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage
700907-2	Caster Assembly	<ul style="list-style-type: none"> Caster assembly for aluminum work cage 6 in. (152 mm) Hi-tech-rub, swivel caster 	700903-1 Collapsible Aluminum Work Cage
SA-1072	Ground Dolly	<ul style="list-style-type: none"> Allows the Spider work cage to be rolled across hard, smooth surfaces such as concrete or asphalt To roll across a tar roof or dirt, use plywood or boards 	ST-17, ST-180
SA-3065	Ground Dolly	<ul style="list-style-type: none"> Allows the Spider work cage to be rolled across hard, smooth surfaces such as concrete or asphalt To roll across a tar roof or dirt, use plywood or boards 	ST-19
SA-1002	Transfer Chain	<ul style="list-style-type: none"> Rugged steel rigging hooks and high quality steel chain for safe and efficient horizontal travel through structural steel Allows for 'walking' the rigging point by transferring weight back and forth from transfer chain to rigging point to move along a beam and around vertical obstacles without lowering the stage to the ground 	ST-17, ST-180, ST-19, 701086-1 Steel Work Cage, 700903-1 Collapsible Aluminum Work Cage
701151-1***	Welding Ground	<ul style="list-style-type: none"> Grounds the suspended platform to the structure Helps meet OSHA 1926.451 (f) (17) 	All products
1581***	Mid-Assembly Arc Guard	<ul style="list-style-type: none"> Protects wire rope between fair lead and bottom arc guard 	All drum and traction hoists
SA-1083***	Drum Hoist Arc Guard Kit	<ul style="list-style-type: none"> Protects wire rope above and below fair lead and below deck Includes Spider welding protection components: <ul style="list-style-type: none"> Mid Assembly (1581) Top Assembly (4485) Bottom Arc Guard: 9 in. (229 mm) removable (700947-1) 	9 in. (229 mm) Spider drums, ST-17, ST-180
SA-1083-1000***	Drum Hoist Arc Guard Kit	<ul style="list-style-type: none"> Protects wire rope above and below fair lead and below deck Includes Spider welding protection components: <ul style="list-style-type: none"> Mid Assembly (1581) Top Assembly (4485) Bottom Arc Guard: 16 in. (406 mm) removable (700953-1) 	ST-180
SA-1083-26***	Drum Hoist Arc Guard Kit	<ul style="list-style-type: none"> Protects wire rope above and below fair lead and below deck Includes Spider welding protection components: <ul style="list-style-type: none"> Mid Assembly (1581) Top Assembly (4485) Bottom Arc Guard: ST-26 removable (701305-1) 	ST-26

*Available in rental fleet only

See page 91. *See pages 224-225

See our Insulation and Welding Accessories on pages 225.