


Circular Modular Platform



Don't see the configuration you need? Call your Spider professional.

See page 87 for dimensions.

Circular Modular Platform Typical Configurations

Drawing Number	Length Of Sides (Ft)	No. Of Sides	Hoists (1,000 lbs)	Platform Weight (lbs)	Live Load (lbs/Pers) *	Min. Inside Diameter A		Reach At Corner B	Max. Outside Diameter C		Reach At Midpoint D
RND3-4	3	4	3	1,272	1,200/4	3 ft	9 in.	7 in.	10 ft	2 in.	10 in.
RND3-5	3	5	3	1,445	1,200/4	5 ft	1 in.	5 in.	11 ft	3 in.	9 in.
RND5-4	5	4	4	1,172	1,200/4	5 ft	9 in.	12 in.	12 ft	4 in.	7 in.
RND3-6	3	6	3	1,338	1,200/4	6 ft	5 in.	4 in.	13 ft	0 in.	15 in.
RND5-5	5	5	3	1,545	1,200/4	7 ft	10 in.	9 in.	14 ft	6 in.	6 in.
RND8-4	8	4	4	1,448	1,200/4	8 ft	9 in.	19 in.	14 ft	8 in.	12 in.
RND3-8	3	8	4	1,784	1,200/4	8 ft	10 in.	2 in.	16 ft	4 in.	10 in.
RND5-6	5	6	3	1,458	1,200/4	9 ft	10 in.	7 in.	17 ft	4 in.	23 in.
RND10-4	10	4	4	1,416	1,200/4	10 ft	9 in.	24 in.	19 ft	9 in.	8 in.
RND8-5	8	5	5	1,810	1,500/5	12 ft	0 in.	15 in.	19 ft	10 in.	18 in.
RND5-8	5	8	4	1,944	1,200/4	13 ft	8 in.	4 in.	20 ft	2 in.	28 in.
RND13-4	13	4	4	1,692	1,200/4	13 ft	10 in.	32 in.	22 ft	5 in.	15 in.
RND10-5	10	5	5	1,770	1,500/5	14 ft	10 in.	18 in.	23 ft	2 in.	22 in.
RND8-6	8	6	6	2,172	1,2800/6	15 ft	1 in.	12 in.	24 ft	5 in.	36 in.
RND15-4	15	4	4	1,772	1,200/4	15 ft	10 in.	37 in.	26 ft	4 in.	19 in.
RND10-6	10	6	6	2,124	1,800/6	18 ft	7 in.	15 in.	27 ft	3 in.	40 in.
RND13-5	13	5	5	2,115	1,500/5	18 ft	11 in.	24 in.	27 ft	8 in.	12 in.
RND8-8	8	8	8	2,896	2,400/8	21 ft	0 in.	8 in.	28 ft	4 in.	28 in.
RND15-5	15	5	5	2,215	1,500/5	21 ft	8 in.	28 in.	31 ft	9 in.	32 in.
RND13-6	13	6	6	2,538	1,800/6	23 ft	10 in.	20 in.	32 ft	5 in.	24 in.
RND10-8	10	8	8	2,832	2,400/8	25 ft	10 in.	10 in.	32 ft	10 in.	14 in.
RND15-6	15	6	6	2,658	1,800/6	27 ft	3 in.	23 in.	36 ft	5 in.	27 in.
RND13-8	13	8	8	3,384	2,400/8	33 ft	2 in.	14 in.	40 ft	10 in.	18 in.
RND15-8	15	8	8	3,544	2,400/8	37 ft	12 in.	16 in.	46 ft	1 in.	20 in.

*Load must be distributed. Higher live loads may be possible with more requirements for distributing loads. Contact your Spider professional.